

# Desk calculators



## MS-80E

### Functions

#### Calculation functions

- Currency conversion
- Pro-percentage
- Mark up with percentage key
- Backspace key
- Sign change (+/-)
- Key rollover

#### Memory

- 4-key memory

### Product features

#### Display

- 8-digit display
- LC display
- Function command signs
- 3-digit comma markers

#### Power

- Solar/Battery powered
- Backup battery
- Auto power off

#### Input

- Double zero key

#### Materials / Outer Appearance

- Plastic keys
- Aluminum panel
- Rubber feet
- Ergonomically shaped keys



101 x 28 x 149 mm



120 g

4549526609909  
EAN Code

[www.casio-europe.com](http://www.casio-europe.com)

**CASIO**

Technical changes and errors excepted. The image sizes do not correspond to the original sizes. The colors may differ slightly from the original.

# Desk calculators



## MS-80E

### Operating instructions for selected functions

**CURRENCY CONVERSION – 1 EXCHANGE RATE**

Definition of the following exchange rate:  
 €1 = \$1.1227 US (exchange rate 1.1227)  
 All versions function the same way and can be operated as follows:

AC    SET %    EURO RATE 1.1227  
Press and hold for about 8 seconds

SET %

The exchange rate is saved.

Conversion of €100 to US\$.

100 LOCAL    112.27  
 Amount in US\$

Conversion of \$100 US to €.

100 EURO    89.07  
 Amount in €

The key label for setting the exchange rate varies slightly depending on the model. The following designations are available: [RATE SET] [RATE SET%] [SET] [SET%]

Pocket and desk calculators

#### Currency conversion

After the desired exchange rate is entered and saved, amounts can easily be converted to another currency. Converting a reference currency into any previously defined foreign currency at the touch of a button is especially advantageous on business trips and for international transactions.

**PROFESSIONAL PERCENTAGE CALCULATION**

Addition of 10% to the reference value 50 with interim display of the amount to be added during the calculation.

50 × 10 %    5

+

55

Subtraction of 10% from the reference value 50 with interim display of the amount to be subtracted during the calculation.

50 × 10 %    5

-

45

Pocket and desk calculators

#### Pro-percentage

Determine percentage-based surcharges and discounts with a separate display of the calculated value. Comfortable calculating percentage markups and markdowns and subsequent display of the calculated absolute value.

**4-KEY MEMORY**

M+ Adding memory

M- Subtracting memory

MR Display of total balance

MC Complete deletion of memory

Addition of 10 and 10 to memory and subtraction of 5 from memory.

10 M+ 10 M+ 5 M-    15  
 MR  
 Content of memory

MC    Memory deleted

MR    0  
 Content of memory

Pocket and desk calculators

#### 4-key memory

Memory buttons can be used to save numbers for later use.